



MOLD HANDLE ASSEMBLY

NOTES:

1. CLEAN AND REMOVE ALL GRIT PRIOR TO FINISHING.
2. BLUE PAINT FINISH ON PLAIN STEEL ITEMS AFTER WELDING, BEFORE FINAL ASSEMBLY.

<p>THIS DOCUMENT AND THE CONTENTS THEREOF IS THE PROPERTY OF HARGER INC., AND IS FURNISHED TO YOU FOR INFORMATION ONLY. THE INFORMATION CONTAINED HEREIN IS CONFIDENTIAL AND OF A PROPRIETARY NATURE AND MUST NOT BE DISCLOSED TO THIRD PARTIES WITHOUT THE EXPRESS WRITTEN APPROVAL OF HARGER INC.</p>				<p>PART NO. RMJHC25013T8FRM T8 250MCM 13" ASSEMBLY</p>			
				<p>LET</p>	<p>A</p>	<p>ADDED NOTE</p>	<p>061504</p>
<p>TOLERANCES UNLESS NOTED:</p>				<p>DATE</p>	<p>BY</p>	<p>SCALE: 1/4</p>	
<p>FRACTIONAL +/- 1/16</p>				<p>DATE: 101303</p>	<p>CHECKED BY:</p>	<p>HARGER™ 301 ZIEGLER DRIVE GRAYSLAKE, IL 60030 (847) 548-8700</p>	
<p>.00 +/- .030</p>							
<p>.000 +/- .010</p>							<p>SHEET: 1 OF 1</p>